

SYRUS SIGFOX COMMUNICATOR

The **Syrus Sigfox** is a radio communication accessory that enables Syrus GPS devices to communicate globally with the first OG global network. Plug & Connect compatible with Syrus GPS devices, easy to program and manage in the Pegasus Cloud Gateway - web application. It is the ideal solution for critical scenarios and activities that request reliable, near real time, communication services including backup for cellular networks.

PART NUMBER

1101-24

Fully programmable events RC2 and RC4 zone capability using Syrus fixed signals using the Sigfox RF network RS-232 transparent communi-Fully integrated and cation with Syrus GPS device / compatible with Pegasus compatible with Syrus three Gateway Ecosystem (3)-Port Serial Expander Works with Syrus' Jamming High gain, low-profile, detection capability to trigger external Sigfox antenna an event *Antenna sold separately*





TECHNICAL SPECIFICATIONS

PHYSICAL				
Unit Dimensions (inches)	4.335 x 2.246 x 1.063			
Material	GRABS UL 94HB Plastic			
ENVIRONMENTAL				
Operating Temperature	-30°C to 85°C			
Storage Temperature	-40°C to 85°C			
Operating Humidity	Up to 75% non-condensing			
Storage Humidity	Up to 93% non-condensing			
ELECTRICAL				
Operating Voltage	8 - 32VDC			
Current Consumption	Idle: 25mA Tx/Rx: 80mA			
NETWORK SPECS				

SFM11R2D

22.5 dBm

Sigfox-Zone RC2/RC4

902.200 MHz - 920.800 MHz

Reference

Network

Frequency Range

Output Power

ACTERISTICS
50 0hm
3.5 dBi
Linear
≤1.9 typical
SMA
863-873MHz and 902-928MHz
712-ANT-8/9-HDP2SMA

ADDITIONAL FEATURES		
Over the air firmware upgrade		
Sigfox message size 12 bytes		
Polarization and transient voltage protection		
MOUNTING		

Screw Mount



PINOUT

COLOR	CABLE	DESCRIPTION
GREEN	MAIN POWER (8-32V)	May be connected to the green cable in Syrus devices (in models 2481 or 2480) or directly to the vehicle's battery.
BLACK	GROUND (OV - GND)	
WHITE	RX	Connects to Syrus TX cable (brown).
BLUE	TX	Connects to Syrus RX cable (purple).

COVERAGE MAP

R C 2 Brazil, Canada, Mexico, Puerto Rico, USA. R C 4 Latin America: Argentina, Chile, Colombia, Costa Rica, Ecuador, El Salvador, Guatemala, Honduras, Nicaragua, Panama, Peru, Trinidad &

Asia Pacific: Australia, Hong Kong, Indonesia, Malaysia, New Zealand, Singapore, Taiwan, Thailand.

PEGASUS CONFIGURATION

COMMANDS			
Set up Destination Address 1 for Syrus Sigfox >SDA1; P16<	Enable the Syrus Sigfox Mode >SXABR19200< >SXASMM1<		
Disable Syrus Sigfox Mode > SXABR115200 < > SXASMM0 <			

^{*} For more information on the latest stable firmware versions, please visit our support website at support.digitalcomtech.com





The ideal solution to trigger jamming detection events.